

Remove the lid from the cubby proper

Remove the 2 \* T40 screws and pull off the silver covers



Pull the lid up and off the cubby proper

Turn the lid over and remove the 8\*T20 screws – 2 are **under** the rubber 'bumpers'. These simply prise out with a small screwdriver.



Prise the lid apart carefully



In my case, the broken part was the silver piece circled – it had snapped off after the lid was banged shut leaving the handle flapping around.



I removed the remnants of the piece and using a small (5 amp?) electrical connector I fashioned a new part by cutting the end off to leave just the 'crimp' section.



Insert the cut connector through the hole in the lid. When putting the handle back make sure the springs sit under their retainer correctly – it's obvious if you get it wrong.

I pushed the handle pin through into the end away from the new piece before sliding it into the new piece. It's a little fiddly but I have hands like Homer Simpson....

Obviously it can be tidied up and a different colour crimp can be used but once the lid is closed it can't be seen anyway. It took longer to write this than to do it.

