Contents Page Page 1 of 2

Published: Feb 7, 2005



Specifications

Lubricants

Item	Specification
* Recommended lubricant	Shell M13754
+ Torque converter nose	Molybdenum disulphide grease to specification FB180



CAUTION: * Do not use any lubricant other than that specified.



CAUTION: + Do not over lubricate.

Capacity

Item	Capacity
+ Initial dry fill	9.5 litres (16.7 pints) (10.0 US qts)



CAUTION: + A final fluid level check/drain down/top-up must be carried out when the unit has been installed.

General Specification

Item	Specification
Automatic transmission	ZF 6HP26
Speeds	6 Forward, 1 Reverse
Gear ratios:	
First	4.17:1
Second	2.340:1
Third	1.521:1
Fourth	1.143:1
Fifth	0.867:1
Sixth	0.691:1
Reverse	3.403:1
Torque converter	Sachs W260 2GWK with slip controlled, dual friction faced lock-up clutch
Transmission control module:	
Location	Located in transmission casing
Туре	1904

Torque Specifications

Description		lm	lb-ft
Transmission fluid filler/level plug][3	5	26
Transmission fluid drain plug)	7
	$\neg \vdash$		

Contents Page Page 2 of 2

Selector lever nut		9
Selector cable bracket bolts		7
Main control valve body Torx screws		6
Fluid pan Torx screws	8	6
Engine RH support bolts	45	33
Transmission heat shield bracket bolts		7
Transmission heat shield bolts	10	7
Wiring harness bracket Torx bolt	10	7
Torque converter bolts	45	33
Transmission bolts	45	33
Radiator access panel bolts	10	7
Breather pipe clip bolt	25	18
Fluid line clip bolt	10	7
Fuel pipe heat shield bolts	10	7
Transmission under shield bolts	10	7
Transmission support insulator	60	44