

P0096	IAT	Sensor range performance
P0101	AFM	Circuit range performance
P102	AFM	Circuit low input
P103	AFM	Circuit high input
P0106	MAP	Sensor range performance
P0107	MAP	Circuit low input
P0108	MAP	Circuit high input
P0111	IAT	Stuck high/low at engine start, stuck high