


7 . Remove the fender air intake grille.

- ▶ Release the 4 clips.
- ▶ Remove the air ducting.



E53026